



**UPS Hygienes Pvt. Ltd.**

(AN ISO 9001-2008 Certified Company)

Customer Care No.: 022-65214567

E-mail: info@upshygiene.com

# ULTRABASIL™ 3Q

## Multipurpose Disinfectant

### Composition :-

Alkyl dimethyl benzyl ammonium chloride 2.37 %

Alkyl dimethyl ethylbenzyl ammonium chloride 2.37 %

**3<sup>rd</sup>** Generation  
Quarternary  
Ammonium  
Compound.

### Features

#### **Bactericidal, Fungicidal, Virucidal, Algacidal.**

- Bactericidal action within 3 min contact time.
- Fungicidal action within 10 mins contact time.
- Gram + ve organisms- S. aureus, E. hirae, L.monocytogenes.
- Gram -ve organisms-Paeuroginosa, E. coli, S. typhimurium, C. jejuni.
- Fungus- C. albicans, A. niger.

\* Effective in presence of heavy organic soiling of surfaces.

\* Dual action- CLEANING & DISINFECTION.

\* Works in any pH, Neutral solution

\* Deodorizer

\* 3 years stability / Aldehyde free

\* Effective on all porous and nonporous surfaces.

\* Water soluble

\* Bio degradable & Eco friendly

\* Non hazardous / Non staining/ Non toxic/ Non corrosive

### How to use

For use on inanimate, hard surfaces like floors, walls, tables, metal surfaces, plastic surfaces in hospitals, clinics, dental clinic, educational institutes, hotels, pharma manufacturing plant, animal areas. Apply with mop or cloth, spray or soaking, wipe with cotton.



## Dilution:

- For critical areas: 1: 64 or 15.62 ml in 1 lit.
- High risk areas like OT, ICU, ICCU, NICU, and AKD.
- For non critical areas: 1: 128 or 7.81 ml in 1 lit.
- Areas like reception, wards, path labs etc.
- For Operation Theatre, to control aerial infection ,pour 16 ml in fogger machine and fumigate for 15 minutes and allow it to dry.

## Why multi purpose ?

- Can be used to disinfect all objects, surfaces in health care, Food & dairy, Hospitality industry.
- Dilute 8 ml Ultrabasil 3Q solution in one lit water and use for following various applications.
- In wards, mop all floorings, wipe all beds, trolleys, tables,
- Pour in toilet, sink and bathrooms.
- In dental clinic mop all floorings, wipe all tables, chairs, sofas, partition, window panels, doors in both waiting area and nearby chair area. Dental chair
- Wipe instruments with cotton.
- Spray in the air, removes odour disinfects environment.



**ENVIRONMENT / SURFACES / FLOORING / INSTRUMENT**

For further details contact :

**UPS HYGIENES PVT. LTD.**

B/ 508, Shiv Parvati Apt, Satyanagar Borivali west, MUMBAI 400092 India.

For Trade Enquiries: E-mail : info@upshygiene.com • Website : www.upshygiene.co.in

Tel. : 9821338361/022-65214567